

Chass item # 00285

Thermo Clock Instruction Manual

Features

- A. Normal Time Display
1. Display hour, minute, month and date.
 2. The setting range is 1900 - 2099.
 3. 12/24 hour Display System.

B. Timer

1. Count Up Timer.
2. Count Down Timer.

C. Alarm

Daily Alarm with Snooze function.

D. Thermometer

Display Celsius or Fahrenheit. The accuracy is $\pm 1.5^{\circ}\text{C}$.

Function Description

A. Normal (Time and Temperature Display)

Shows current time on upper display. Lower display shows month, date, day of week & temperature.

1. Press "MODE" to show alarm time.
2. No function with "UP".
3. Press "^{DOWN}" to switch 12 Hour & 24 Hour display.
4. Press "C/F" to switch Celsius / Fahrenheit display.
5. Press "LIGHT/SNOOZE" to turn on lamp for 5 seconds.

B. Time Set Mode

1. Slide the switch to the "TIME SET" position to enter time set mode.
2. Press "MODE" to switch to the setting items. The sequence is Hour → Minute → Year → Month → Date → Back to Hour. The item under setting is blinking.
3. Press "UP" or "^{DOWN}" to adjust the item value.

4. When the time set, the day will be automatically changed and the second will be back to zero.

5. Slide the switch to the "NORMAL" position to quit the "TIME SET" mode.

C. Alarm Set Mode

1. Under the normal time display mode, hold "MODE" to display the alarm setting time.
2. Slides the switch to the "ALM SET" position to enter 'ALARM SET' mode.

3. Press "MODE" to switch to the setting items. The sequence is Hour → Minute → Snooze → Back to Hour.
4. Press "UP" or "^{DOWN}" to adjust the item value.

Remark: The setting of the Snooze is the time between the alarms.

The range is 1 - 60 minutes.

5. Slide the switch to select the alarm function:

- a. 'Alarm On': Alarm On, Snooze Off - The alarm sounds once for 1 minute.
- b. 'Snooze': Alarm On, Snooze On - The alarm sounds 3 times, each sound is last for one minute and the time between snooze can be set.
- c. 'Alarm Off': Alarm Off, Snooze Off - No alarm sounds.

6. Under the Alarm On state, when the alarm time is up, the alarm is last for 1 minute, press any key to stop the alarm.

7. Under the Alarm On- Snooze On state, when the alarm time is up, the alarm is last for 1 minute, press "LIGHT/SNOOZE" to pause the alarm, it will alarm again after 1 minute which depends on the "SNOOZE" setting. Press other keys to stop the alarm.

D. Timer Set Mode

1. Slides the switch to the "TIMER SET" position to enter "TIMER SET" mode.
2. Press "MODE" to switch the setting items, the sequence is Count Down Timer → Count Down Timer Hour Setting → Count Down Timer Minute Setting → Count Down Timer Second Setting → Count Up Timer → Back to Count Down Timer.

Remark : The starting of the sequence depends on the last mode which is operated.

3. Count Up Timer

a. Under the count up timer mode, press "LIGHT/SNOOZE" to start or pause the timer.

b. When the count up timer pauses, press "MODE" to set the time to zero.

4. Count Down Timer

a. The default count down timer is 29:59:59.

b. Under the TIMER SET mode, press "MODE" to set the item, the sequence

is Hour → Minute → Second.

c. Press "UP" or "^{DOWN}" to adjust the item value. (The range is 1-30 hours).

d. Press "LIGHT/SNOOZE" to start/pause the count down timer.

e. When the timer pauses, press "MODE" to recover the time is 29:59:59.

5. Slides the switch to the "NORMAL" position to quit the "TIMER SET" mode.

Remark: If the clock has any problem, use the pointed object to insert the 'Reset' hole at the back of the case.