




Instruction Sheet

This high quality miniature timepiece is operated by a type SR626SW button cell battery. Under normal conditions, the battery should operate your clock for at least 1-2 years.



Pull out crown
to set the time

To adjust the time:

1. Pull out the adjusting knob to the "set" position.
2. Turn knob until the desired time is shown.
3. Push the adjusting knob back to the "normal" position.

To Clean

Use a soft cloth , do not use any chemicals or soap.