



HANDY METAL METRIC CALCULATOR



CONVERSION TABLE	DISPLAY ICON	
1 Inch = 2.54 Centimeter	IN	Inch
	CM	Centimeter
1 Foot = 12 Inch = 0.3048 Meter	FT	Foot
	M	Meter
1 Yard = 3 Foot = 0.9144 Meter	YRD	Yard
	M	Meter
1 Mile = 1.609344 Kilometer	ML	Mile
	KM	Kilometer
1 Imperial Gallon = 4.54609 Liter	IMPGAL	Imperial Gallon
	LTR	Liter
1 US Gallon = 3.7854118 Liter	US.GAL	US Gallon
	LTR	Liter
1 Pound = 0.4535924 Kilogram	LB	Pound
	KG	Kilogram
	°F	Degree Fahrenheit
	°C	Degree Celsius
	Ⓕ	Foreign Currency
	Ⓕ	Home Currency
	AMT	Amount
	TAX+	Add Tax



PGNS90755
(EN/FR/DE/DO/SP/IT)

FEATURES

- 8 Units Metric Conversion Calculator
- 2 Currencies Money Exchange
- Consumer Tax Calculation
- 8 Digits Dual Power Calculator
- Auto Power Off


TURN ON/OFF THE CALCULATOR

- Press **ON/OFF** button to turn on the calculator.
- The calculator will turn off automatically in around 5-8 minutes after the last operation.
- The calculator will remain at the last operation mode after auto power off.



CONVERSION MODE

- Press **CONV** to change to Metric Conversion mode.
- Press **UNIT** to select input column (Upper / Lower) for the measurement unit.
- Press **UNIT**, measurement unit will be shown by sequence.
- Units available in the upper column: **IN** → **FT** → **YRD** → **ML** → **IMPGAL** → **US.GAL** → **LB** → **°F** → **Ⓕ** → **AMT** for conversion input.
- Units available in the lower column: **CM** → **M** → **M** → **KM** → **LTR** → **LTR** → **KG** → **°C** → **Ⓕ** for conversion input. (except **TAX+**)
- Input exchange data, the corresponding conversion value will be shown.



TO CHECK RATE

- This function allows to check the default conversion rate.
- In the Metric Conversion mode, Press **UNIT**, then press **UNIT** to check measurement conversion rate, currency exchange rate or tax percentages (except the temperature rate).

Remarks: All the conversion rate is according to the standard conversion rate. The default rate cannot be changed by the end users except the money exchange rate and the consumer tax rate. The rate of the temperature is indirect proportion, the conversion rate for **°C** & **°F** cannot be shown in the check rate mode.

TO SET "HOME" CURRENCY EXCHANGE RATE

- In the Metric Conversion mode, press **UNIT** to "Ⓕ" item is shown.
- Press **UNIT**, the pre-set exchange rate will appear.
- Press the **UNIT** again, the pre-set exchange rate will be blinking.
- Input new exchange rate, then press **UNIT** to confirm.

Remarks: Users can only set the **Ⓕ** (Home currency) while the **Ⓕ** (Foreign currency) is input time by time.



TO SET "TAX+" TAX PERCENTAGE

- In the Metric Conversion mode, press **UNIT** to "TAX+" item is shown.
- Press **UNIT**, the default rate will appear.
- Press the **UNIT** again, the exchange rate will be blinking.
- Input new tax percentage, then press **UNIT** to confirm.

Remarks: Users can only set consumer tax rate while the amount is input time by time in each calculation. If the consumer tax is 5%, the amount of good is \$100, the total payment is \$105. (e.g. for 5%, input "5" for 10% = input "10")



CALCULATOR MODE

- Press **ON/OFF** button to calculation mode.
- 8 digits with four basic calculation, percentages, M+, M-, MRC.
- The memory can be stored between conversion mode and calculator mode.

CHANGE THE BATTERY

Slide out the battery compartment and replace with a new 1.5V button cells battery (LR1130 / V10GA) in correct polarity.

The hole at the back of the machine allows the user to reset the machine. Press the hole with a needle or sharp pencil when the device is not working properly due to electrostatic discharge disturbance or after battery changed, the unit will reset automatically. (For example the calculator has been misused). All memories and rates will be lost after the re-set.