


Chass Item # 72770



How to set time

To Set Time

1. Place battery on the right position.
2. Turn TIME SET dial on the back of the clock until the correct time is reached.

To Replace Battery

1. Remove the battery cover from the back of the clock.
2. Replace used battery with new UM3 battery or equivalent. Put the (+) and (-) of the battery on the right position.

Réglage de l'heure.

Pour régler l'heure

1. Placer la pile selon la position correcte.
2. Tourner le bouton « TIME SET » situé au dos de l'horloge, jusqu'au réglage de l'heure courante.

Pour remplacer la pile

1. Oter le couvercle du compartiment à pile du dos de l'horloge.
2. Remplacer la pile usagée par une pile AM3 neuve ou équivalente. Place la pile selon les polarités indiquées: « + » et « - ».

Como se pone la hora

Para poner la hora

1. Coloque la pila en la posición correcta.
2. Maneje el botón de PONER-HORA en la parte detrás del reloj hasta que la hora correcta haya sido puesta.

Para cambiar la pila

1. Saque la tapa de la pila a la espalda del reloj.
2. Cambie la pila usada con una nueva AH3 pila o equivalente. Meta el lado (+) y (-) de la pila en su propia posición.