



# INSTRUCTIONS



**Chass Item #73130**

- To insert or replace battery ↑
- To replace clock into case ↓



Replace fit up into case, with back going into the case opening, line up to 12 o'clock gently and slowly press bezel to a flush position. Some side to side rocking may help flush fitting as illustrated.