


Chass Item #73200 "Grand Admiral" Clock

To set time or replace battery:

- Grasp the clock bezel that surrounds the clock movement, (round metal ring).
- Pull the clock movement out of the clock case to expose the back, the battery compartment and time setting button is found there.

QUARTZ DESK CLOCK USER'S INSTRUCTION



TIME SETTING TUNING BY THE BUTTON

FIG. 1



TIME SETTING:

Set time by turning the time setting button. (see Fig.1)

BATTERY INSTALLATION AND REPLACEMENT:

The clock may not come with a battery installed. When the clock loses time or stops the battery is due for replacement. The battery is accessible from the backside of the clock. Opened the back door. (see Fig.1) Then the battery can be taken out from the movement. Replace with UM3 cell. Make sure that it is retained securely in position by the metal plate. Closed the back door in reverse procedure.

BATTERY TYPE:

UM3, R6, AA size or equivalent.